

Battery Operated Candle with Suction Cup

VT-9134 Series

(For Indoor Use Only)

INSTRUCTIONS

1. Unscrew the bulb.
2. Insert 3x AA alkaline batteries (+) positive side up.

NOTE: *Do not force the battery into the candlestick. Guide the battery past the metal contact at the top of the candlestick, and then it should drop with ease.*

IMPORTANT BATTERY INFO: *Use only new, fully charged alkaline batteries. Do not mix new and old batteries. Lithium, rechargeable, and heavy duty batteries are not recommended because battery life will be significantly reduced.*

3. Replace bulb.
 - Candle will turn on once the bulb is fully screwed in.
 - The 6-hour timer is now set and will repeat daily.
 - To reset timer, unscrew the bulb and screw back in at desired start time.

WINDOW & SUCTION CUP INSTALLATION

Be sure to follow these steps to ensure candle grips well to your window.

1. Clean window and allow to dry before installing.
2. Position suction cup onto candlestick where appropriate. Slide up and down to adjust. Be sure to spin the candle so that the LEDs are pointing to the outside.
3. Press firmly at the center of the suction cup so that it flattens out fully and removes all air. Candle should now be held firmly in place.

NOTE: *For best results, surface should be above 40°F when applied. Changes in temperature or humidity may gradually make cups lose suction. We recommend installing these candles to double or triple pane windows only.*

Rollier Hardware, Inc
DBA 612 Vermont®
600 Washington Rd
Pittsburgh, PA 15228
www.612vermont.com

Made in Taiwan

(Flip Over for Features & Warranty Information)

Battery Operated Candle with Suction Cup

VT-9134 Series

(For Indoor Use Only)

FEATURES

Dual Intensity LED Bulb

- Cool to the touch
- Shines bright towards the street and softly inside.
- *US Patents D700,378 & 9,976,716 B1 (Patents owned by GHH, Inc.)*

Automatic Daily Timer

- Turns ON when batteries are installed. Timer is automatically set for 6 hours ON and then 18 hours OFF. Repeats daily.

Suction Cup with Clip

- Allows for placement anywhere on window

Shatterproof Bulb

- Designed not to break if the candle falls from the window.

CARE

- Remove alkaline batteries when not in use. Batteries left in the candle when not in use can leak and cause corrosion.
- Replace alkaline batteries when the candle dims.
- Dispose of used batteries responsibly.
- Store in a temperature controlled environment with normal humidity.
- Clean with a non-abrasive cleaner.

3 YEAR WARRANTY

Our warranty covers any defect out of the box or any problems that may occur within three years of the purchase date. Warranty does not cover damages caused by improper use, storage, or handling.

We strive to make this process simple and pain-free!

For the most efficient service, please email us through our website: www.612vermont.com. If preferred, call us toll-free: 1-877-750-0971.

REPLACEMENT PART(S) INFORMATION

- Replace the bulb with model # VT-9222-4R-W.
- Replace candlestick tube with model # VT-TUBE3AAW.

WARNING! This product is not a toy and not intended for use by children. Adult use only.

(Flip Over for Instructions & Installation)